



- Operator's Manual 107
- Engine Gasket Kit 108
- Spark Arrestor 104

Vacuum Tube/Blower Tube Ass'y.



SEARS GAS BLOWER MODELS 358.797922, 358.797982

Carburetor Assembly Part Number 530-035262 WA-207/207A



Carb.
Repair
Kit

17

Carb.
Gasket
Kit

18

Model Blower* - 358797922 (SEARS GAS BLOWER)

Part Description	Part Number	Diagram Reference Number
HANDLE	530-094712	1
FRONT ISOLATOR	530-026994	2
SPACER	530-029111	3
SCREW	530-015635	4
REAR ISOLATOR	530-029130	5
SCREW	530-015813	6
TRIGGER	530-029072	7
SPRING	530-027597	8
"C" CLIP	530-015702	9
THROTTLE LOCK BUTTON	530-029117	10
PIN	530-015840	11
SPRING	530-024772	12
SHROUD-LEFT (MODEL 358.797960)	530-029068	13
SHROUD-LEFT (MODEL 358.797922 & 358.797982)	530-029610	13A
SHROUD-RIGHT (MODEL 358.797960)	530-029067	14
SHROUD-RIGHT (MODEL 358.797922 & 358.797982)	530-029609	14A
GROMMET	530-019168	15
SWITCH	530-069292	16
ISOLATOR	530-029129	17
ISOLATOR	530-029089	18
SCREW	530-015814	19
FUEL TANK ASS'Y. (INCL. #21, 22 & 106)	530-014121	20
FUEL CAP (INCL. O'RING)	530-010729	21
FUEL PICK-UP ASS'Y.	530-010897	22
HANDLE COVER ASS'Y. (INCL. 9, 10 & 12)	530-014160	23
COVER	530-029071	24
AIR FILTER	530-029112	25
ASSIST HANDLE (MODEL 358.797982 ONLY)	530-094740	26
MUFFLER	530-069293	27
SPRING	530-029116	28
SPARK PLUG	530-030073	29
SCREW	530-015239	30
MODEL NO. 358.797922 & 358.797982	530-012235	31B
MODEL NO. 358.797960	530-012244	31A
CYLINDER	N/P	31
LEAD WIRE	530-029145	32
IGNITION MODULE	530-039137	33
MODEL 358.797960	530-015776	34A
MODEL 358.797922 & 358.797982	530-015816	34B
SCREW	N/P	34
GASKET	530-019178	35
MODEL NOS. 358.797922 & 358.797982	530-025875	36B
MODEL NO. 358.797960	530-026413	36A
PISTON RING	N/P	36
MODEL NO. 358.797960	530-069274	37A
MODEL NOS. 358.797922 & 358.797982	530-069349	37B

PISTON KIT (INCL. #36, 38, & PIN)	N/P	37
RETAINER	530-015162	38
SCREW	530-015306	39
GROUND WIRE	530-029144	40
SCREW	530-015849	41
WAVE WASHER	530-015254	42
SPACER	530-027528	43
CHOKE SHUTTER	530-029114	44
SCREW	530-015771	45
CABLE ASSEMBLY (INCL. #45)	530-029146	46
PLATE	530-029115	47
CARBURETOR	530-035263	48
GASKET	530-019164	49
SEAL	530-019165	50
SCREW	530-015775	51
GROUND WIRE	530-029113	52
REED BLOCK	530-029070	53
GASKET	530-019166	54
REED VALVE	530-027593	55
REED STOP	530-027594	56
SCREW	530-015241	57
CRANKSHAFT ASS'Y.	530-014033	58
KEY	530-015126	59
MODEL NOS. 358.797922 & 358.797982	530-010960	60B
MODEL NO. 358.797960	530-014005	60A
PISTON ROD	N/P	60
SPACER	530-015788	61
INNER BEARING	530-032103	62
RING	530-015787	63
CRANKSHAFT SEAL	530-019158	64
OUTER BEARING	530-032102	65
RETAINING RING	530-015789	66
CRANKCASE	530-014016	67
FLYWHEEL	530-039136	68
WASHER	530-347987	69
SPRING	530-023817	70
SPACER	530-029176	71
CRANKCASE/CRANKSHAFT ASSY.	530-014156	72
SCREW	530-015823	73
SCREW	53-015496	74
RETAINER	530-027523	75
STARTER PULLEY (INCL. 73)	530-069486	76
STARTER SPRING	530-029395	77
FAN HOUSING	530-069563	78
STARTER HANDLE	530-027569	79
SCREW	530-015769	81
BEARING	530-032108	82
SPACER	530-029110	83
SCREW	530-015805	84
"O" RING	530-019167	85
EYELET	530-029182	86

SCREW	530-015805	87
RETAINER	530-027523	88
ROLL PIN	530-029119	89
BLOWER HOUSING (UPPER)	530-094710	90
BAND	530-029173	91
IMPELLER	530-094714	92
HUB	530-029118	93
WASHER	530-015818	94
WASHER	530-015441	95
NUT	530-015472	96
BLOWER HOUSING (LOWER) (INCL. 99-103)	530-094711	97
SCREW	530-015367	98
DOOR	530-094715	99
CARTON (MODEL 358.797960)	530-061189	None
CARTON (MODEL 358.797982)	530-061347	None
CARTON (MODEL 358.797922)	530-061350	None
SPRING	530-015667	100
PIN	530-015647	101
SCREW	530-015815	102
SPRING	530-015672	103
SPARK ARRESTOR KIT	530-069348	104
ROPE KIT	530-069232	105
LINE KIT	530-069247	106
OPERATORS MANUAL	530-068243	107
GASKET KIT	530-069294	108
AIR BAFFLE	530-029404	109
WASHER	530-015811	110
SPACER 358.797960 ONLY	530-027525	111
MUFFLER GUARD	530-069303	112
CAP 358.797922 & 358.797960 ONLY	530-029460	113
MODEL NO. 358.797960	530-029179	114B
MODEL NO. 358.797922 & 358.797982	530-036274	114A
DECAL INSTRUCTION	N/P	114
SCREW	530-015843	115

Model Blower* - 358797922 (CARBURETOR ASSY. P/N 530-035219)

Part Description	Part Number	Diagram Reference Number
METERING DIAPHRAGM	530-035014	1
METERING DIAPHRAGM GASKET	530-035151	2
METERING LEVER PIN SCREW	530-035016	3
MIXTURE NEEDLE	530-035268	4
MIXTURE NEEDLE SPRING	530-035214	5
MIXTURE NEEDLE WASHER	530-035217	6
"O" RING MIXTURE	530-035218	7
FUEL PUMP DIAPHRAGM	530-035166	8
FUEL PUMP GASKET	530-035164	9
IDLE SPEED SCREW	530-035203	10
IDLE SPEED SPRING	530-035208	11
METERING LEVER PIN	530-035028	12
METERING LEVER	530-035031	13
METERING LEVER SPRING	530-035188	14
INLET NEEDLE VALVE	530-035106	15
FUEL INLET SCREEN	530-035178	16
CARB. KWIK REPAIR KIT	530-035260	17
CARB. GASKET/DIAPHRAGM KIT	530-035219	18
CARTON (MODEL 358.797960)	530-061189	None
CARTON (MODEL 358.797982)	530-061347	None
CARTON (MODEL 358.797922)	530-061350	None

Model Blower* - 358797922 (VACUUM TUBE/BLOWER TUBE AS

Part Description	Part Number	Diagram Reference Number
COLLECTION BAG W/STRAP	530-069272	1
COLLECTION BAG ELBOW TUBE	530-094764	2
VACUUM TUBE	530-069270	3
BLOWER NOZZLE-FLARE	530-094662	4
BLOWER NOZZLE-CONCENTRATOR	530-351455	5
BLOWER TUBE	530-094664	6
HANDLE	530-010850	7
CLAMP	530-094230	8
OPERATOR'S MANUAL	530-067306	9
ASSIST HANDLE	530-094740	10
SCREW	530-015814	11
CARTON (MODEL 358.797960)	530-061189	None
CARTON (MODEL 358.797982)	530-061347	None
CARTON (MODEL 358.797922)	530-061350	None